



- 1. Nozzles
- 2. Packing gland
- 3. Pump plunger with handle
- 4. Pump mounting bracket
- 5. Hose clamp
- 6. Hose
- 7. Shoulder carrying strap
- 8. 5 gallon water tank
- 9. Tank strainer inside of fill opening
- 10. Tank cap, vented type

The back pump has four basic parts which contain many smaller parts. The major parts are: the tank, shoulder harness straps, hose, and pump assembly.