

- | | <u>POINTS</u> |
|---|----------------------|
| 1. When walking the "Golden Circle" what should you be watching for? (List four) | <u>20</u> |
| 1. _____ | |
| 2. _____ | |
| 3. _____ | |
| 4. _____ | |
| 2. A _____ must be worn whenever a state vehicle is moving. | <u>10</u> |
| 3. To release the spring brake on a CDF engine, air pressure must be at least _____. | <u>10</u> |
| 4. On a model #1 or #5 engine, what will happen when you try to move an engine with the midship pump engaged? | <u>10</u> |
| 5. Under normal conditions an engine equipped with a transfer case should be placed in _____ prior to movement. | <u>10</u> |
| 6. When a CDF engine with an automatic transmission is parked, what gear should the transmission be left in? | <u>10</u> |
| 7. When a CDF engine is parked on the fire line, where should the keys be left? | <u>10</u> |
| 8. When parking a CDF engine with a manual transmission, which gear should the transmission be left in? | <u>10</u> |

9. Even in emergency circumstances, a _____ person should be used, if available. **POINTS** 10

POINTS POSSIBLE: 100

POINTS DEDUCTED:

FINAL SCORE:

	<u>POINTS</u>
1. When walking the "Golden Circle" what should you be watching for? (List four)	<u>20</u>
1. OPEN COMPARTMENTS	
2. EGRESS OBSTACLES	
3. HAZARDS	
4. DEPLOYED HOSE LINE LOOSE EQUIPMENT INATTENTIVE PERSONNEL	
2. A SEAT BELT must be worn whenever a state vehicle is moving.	<u>10</u>
3. To release the spring brake on a CDF engine, air pressure must be at least 60 PSI.	<u>10</u>
4. On a model #1 or #5 engine, what will happen when you try to move an engine with the midship pump engaged?	<u>10</u>
ENGINE WILL NOT MOVE, BUT MIDSHIP PUMP WILL THROTTLE UP	
5. Under normal conditions an engine equipped with a transfer case should be placed in HIGH RANGE prior to movement.	<u>10</u>
6. When a CDF engine with an automatic transmission is parked, what gear should the transmission be left in?	<u>10</u>
NEUTRAL	
7. When a CDF engine is parked on the fire line, where should the keys be left?	<u>10</u>
IN THE IGNITION	

	<u>POINTS</u>
8. When parking a CDF engine with a manual transmission, which gear should the transmission be left in?	<u>10</u>

FIRST OR REVERSE

9. Even in emergency circumstances, a BACK-UP person should be used, if available.	<u>10</u>
---	-----------

POINTS POSSIBLE: 100

POINTS DEDUCTED:

FINAL SCORE: