





DOUBLE-BIT AXE




SHARPENING PROCEDURES



The axe at left was improperly used and maintained, resulting in the head becoming cracked and eventually chipping off, at the cutting edge.

SHARPENING PROCEDURES

Secure tool in vise before sharpening. Use wood blocks to protect head from vise.



•Always use gloves and goggles while sharpening.